How to plug in the FC interface



Overview

Support If the switch connects to a node through an FC interface or FC aggregate interface, as a best practice, assign the interface to a VSAN as an access.

Key Takeaways

To plug in an FC interface, connect the FC optical module, configure the port mode, and verify the link status to ensure proper SAN connectivity. Step 1: Physical ConnectionInsert the FC optical module into the FC interface on your switch or server adapter.

Connect the F

C cable from the interface to the target device (e.g., storage array) or FC switch.

Check the LIN

K indicator; a steady green light indicates the interface is up and ready for configuration. Step 2: Configure Port ModeEnter the system configuration mode on your switch or server. For example, on Huawei devices: CodeCopy system-view port mode fc 10ge 1/21/1 Confirm the operation if prompted, as configuring the port may overwrite existing settings.

On Cisco Nexus switches, FC ports can be configured as downlinks (to servers) or uplinks (to SAN fabric) and support modes like F, E, TE, TF, and Auto. Step 3: Set Topology and SpeedFor direct-attached connections, configure the port topology as Direct.

© 2026 METRA FIBER MARKET - All rights reserved

In Net

App System Manager, navigate to Network > FC ports, select the port, choose Edit topology, and set it to Direct. Configure the port speed to match the connected device rather than using autonegotiation to reduce reconnection delays. Step 4: Create Logical Interfaces (Optional)If required, create a Logical Interface (LIF) for the FC port.

Assign a name, select the protocol (FC or NVMe/FC), choose a subnet if applicable, and select the home port. The port will come online automatically once the LIF is created. Step 5: Verify Interface StatusCheck the interface status to ensure it is operational.

On Huawei devices: CodeCopy[~HUAWEI] display interface FC1/21/1 The output should show current state: UP and line protocol current state: UP.

On Cisco or H3

C switches, verify that the port is recognized in the fabric and that the WWN and FC ID are correctly assigned. Step 6: Connect to SAN or HostFor initiator ports, connect directly to storage devices or tape libraries. For target ports, connect to FC switches in the SAN fabric.

Ensure all devices in the SAN support FC and that the WWNs are unique for proper communication. Following these steps ensures that your FC interface is properly plugged in, configured, and ready for SAN communication.

Article Content

Configuring FC interfaces

An FC interface connects to a node (server or disk) or FC switch for transmitting and receiving FC frames. To connect to an FC interface of a peer device, you must use an FC interface. An FC

How to Configure Fibre Channel (FC) Storage on Proxmox VE 9

In this guide, we''ll walk through how to configure Fibre Channel storage on Proxmox VE 9 — step by step. Proxmox VE doesn''t have a dedicated Fibre Channel storage plugin. Instead, it

Example for Configuring an FCF (FC Interfaces)

This document describes the configurations of Trill, FC and FCoE, DCB, and NLB Server Cluster Association.

Configuring an FC Interface

© 2026 METRA FIBER MARKET - All rights reserved

Configuring an FC Interface Before configuring an FC interface, connect an FC optical module to the FC interface. If the LINK indicator is steady green, the FC interface is Up. # Switch 10GE1/21/1 to an FC

Commands for managing FC adapters

You can use FC commands to manage FC target adapters, FC initiator adapters, and onboard FC adapters for your storage controller. The same commands are used to manage FC adapters for the

Configure FC adapters

Hosts can be directly connected to FC adapter ports on AFF, ASA, ASA r2 and FAS systems. Direct-attachment capability can be especially valuable in remote sites

Example: Setting Up Fibre Channel and FCoE VLAN Interfaces in an

To transmit Fibre Channel (FC) traffic between FCoE devices and a storage area network (SAN) FC switch, you configure a local FC fabric on the gateway. The gateway FC fabric includes FCoE and

Configuring a Physical Fibre Channel Interface

Native FC interfaces connect to the storage area network (SAN) FC switch. You can configure ports xe-0/0/0 through xe-0/0/5 as fc-0/0/0 through fc-0/0/5, and ports xe-0/0/42 through xe-0/0/47 as fc

Camo Studio

Camo uses the incredible cameras you already own to produce pro-quality video, whether you''re meeting, streaming, or recording. Its intuitive

Software & Plugins | Focusrite

Software Cubase Register your Focusrite Scarlett audio interface and save 20% when you upgrade from Cubase LE to Cubase Elements, Artist, or Pro. Cubase

How to Connect and Flash BLHeli_32 ESC

Learn how to connect and flash BLHeli_32 ESCs with our step-by-step guide. Download software, configure settings, and update firmware for optimal performance.

After Effects plug-ins, free third-party plugins | After Effects ...

Add even more capability to Adobe® After Effects® using third-party plugins. The plugins listed below work with our latest release, After Effects 2022, and support Multi-Frame Rendering for

Database Tools and SQL | IntelliJ IDEA Documentation

© 2026 METRA FIBER MARKET - All rights reserved

This section provides an overview of basic functionality that is available with the Database Tools and SQL plugin in IntelliJ IDEA. For more

BYD leak shows Flash Charging app as 1,500 kW network prepares

BYD appears to be preparing a Flash Charging app interface as it accelerates nationwide deployment of its megawatt charging network. Circulating screenshots of the interface show plug-and

RSB2A080BD

Schneider Electric Thailand. RSB2A080BD - interface plug in relay, Harmony Electromechanical Relays, 8A, 2CO, without LED, without lockable test button, 24V DC.

Antares AutoTune 2026 with FREE AutoKey2 and

Antares AutoTune 2026 is a complete reimagining of Antares flagship pitch correction technology, delivering the same professional results in a new, efficient

RSB1A120F7

Schneider Electric Thailand. RSB1A120F7 - interface plug in relay, Harmony Electromechanical Relays, 12A, 1CO, without LED, without lockable test button, 120V AC.

Professional Wireless Lavalier Microphone, Plug And Play Wireless ...

To find out about the Professional Wireless Lavalier Microphone, Plug And Play Wireless Microphone, Professional Intelligent Noise Reduction, Omnidirectional Condenser, Windscreen, USB

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

© 2026 METRA FIBER MARKET - All rights reserved

Contact Us

Continue your research online:

Website: https://metramarket.es
Technical inquiry: https://metramarket.es/contact.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 METRA FIBER MARKET - All rights reserved